

LEGEND

1. TORO TMC-424 CONTROLLER. MODEL DISPLAYED: TMC-424-ID. FLOW SENSOR CONNECTION IS SAME FOR TMC-424-OD.

3. TORO TSM-4F OR TSM-8F FLOW MODULE. MODEL DISPLAYED: TSM-8F

3. FLOW MODULE MAY BE INSTALLED IN ANY MODULE SLOT (I, II, OR III). UP TO THREE SEPARATE FLOW MODULES CONNECTED TO THREE SEPARATE FLOW SENSORS MAY BE INSTALLED.

TORO-IRRIGATION DIVISION 5825 JASMINE STREET RIVERSIDE, CA 92504 TOLL FREE: 1-800-664-4740 PHONE: (951) 785-3152 FAX: (951) 359-1870

www.toro.com

NOTE: SEE ADDITIONAL DETAIL DRAWINGS FOR MOUNTING AND INSTALLATION OF TMC-424 CONTROLLER AND FLOW SENSOR. SEE PLANS, LEGEND AND SPECIFICATIONS FOR ADDITIONAL INSTALLATION NOTES. RED WIRE TO + ON FLOW MODULE BLACK WIRE TO-RED WIRE TO-- ON FLOW + ON FLOW **MODULE** MODULE BLACK WIRE TO FLOW SENSOR - ON FLOW MODULE

SECTION/ELEVATION

NOT TO SCALE

NOTES:

- 1. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURERS SPECIFICATIONS.
- 2. DO NOT SCALE DRAWINGS.
- 3. CONTRACTORS NOTE: FOR PRODUCT AND COMPANY INFORMATION VISIT www.CADdetails.com/info REFERENCE NUMBER 065-251.



065-251